

MuxLab 500816 “8 Button RS232/IR Control Panel” Software Package

This Package includes the following:

- The 500816 “Control Panel PC Software”

Use this software running on a PC computer with Windows, to program the 500816 keys via either the 500816 USB or RS232 port.

- The 500816 “USB port Windows 7, 8 & 10 Driver”

Used, if required, to install the 500816 “USB Windows driver”, in order to be able to access and program the 500816 via the USB port.

To program the 500816 “8 Button RS232/IR Control Panel” follow the below steps:

- **Step 1:** Unzip this software package.
- **Step 2:** Connect the 500816 “8 button RS232/IR Control Panel” to your computer USB or RS232 port. This must be the computer you intend to use to program the 500816 keys.
- **Step 3:** Run the Control Panel PC Software.
- **Step 4:** If using the USB port, you may need to install the 500816 “USB Windows Driver”, if requested. In this case provide the location on your hard disk where these drivers have been saved. After installing the 500816 “USB Windows Driver”, then run the 500816 “Control Panel PC Software” again.
- **Step 5:** Refer to the 500816 “8 Button RS232/IR Control Panel” Operation Manual for instructions on how to program the keys.