

Programming Procedure For the 500816-IP

- Controlled Copy
- Uncontrolled Copy

CHANGE AND REVISION HISTORY

Issue Date	Rev.	Reasons of change	CTRL#	Prepared by
2020-03-18	A	First Version - Draft	PRN378	Muxlab

TABLE OF CONTENTS

1. PURPOSE2

2. SCOPE.....2

3. INSTRUCTIONS.....3

4. REFERENCES6

5. ATTACHEMENTS6

1. PURPOSE

This document defines the programming procedure for the 500816-IP.

2. SCOPE

This document covers the steps required in order to properly upgrade the program the 8 buttons panel.

3. INSTRUCTIONS

1. Connect the unit that needs to be upgraded directly to the computer using an Ethernet Patch Cord. Power the unit using a PSU.
2. Run the program “ProBootLoader.exe”.




Figure 1: Firmware Update tool

4. Click the check box beside the unit to upgrade. Select the update firmware file and click the Update Icon to begin the upgrade process. The progression bar will show the upgrade process of the unit.




Figure 3: Update file selection

